

INSTRUCTION MANUAL

Bain Marie

GENERAL INSTRUCTIONS

Carefully read the instructions and retain for future reference. Before connecting the appliance make sure that the data on the technical plate correspond with those of the power supply. The installation must be carried out by professionally trained personnel and in accordance with the instructions of the manufacturer and current regulations.

The manufacturer declines all responsibility for:

Any damage resulting from ignoring the instructions for installation and use or from irregular use of the appliance.

Any inaccuracies contained in this booklet due to translation or printing errors.

The manufacturer reserves the right to make alterations as necessary, without changing its basic characteristics.

INSTALLATION INSTRUCTIONS

1.1 The technical plate is fixed to the back of the appliance.

1.2 Remove protective film.

1.3 ELECTRICAL SAFETY RULES:

Please observe these essential rules:

- the mains voltage and that on the plate must be the same.
- connection must be to a REGULATION earthed socket.
- connection must be to a suitable supply.

The electrical connection must be carried out by trained personnel in accordance with current regulations.

The power cable must be positioned so that no part of it reaches a temperature 50°C above room temperature.

Before installation make sure the socket or switch used can be easily reached when the appliance is in place.

THE MANUFACTURER DECLINES ALL RESPONSIBILITY IF THESE SAFETY RULES ARE NOT OBSERVED.

INSTRUCTIONS FOR USE

2.1 The appliance is intended for general use and must be used by properly trained personnel only.

2.2 Before switching on the machine for the first time, thoroughly clean the Bain Marie.

STARTING UP

3.1 Put the plug into the power socket.

3.2 Turn the thermostat to the required temperature setting. The heating light will come on and will go off when the temperature is reached.

3.3 The appliance is now ready for use.

3.4 In the wet well (optional) Bain Marie there must always be water in the inside container during operation.

3.5 Put the separate containers with the food products into the Bain Marie.

TURNING OFF

4.1 Put the thermostat in position "O".

4.2 NOTE: If the plug remains inserted, the appliance is still under voltage.

MAINTENANCE

5.1 Regular cleaning is essential to ensure the best cooking results and that the equipment remains reliable and efficient.

5.2 IMPORTANT: Before carrying out any cleaning operation, disconnect the appliance from the mains and wait for the elements to cool.

PROBLEMS?

6.1 Check the following:

- Ensure that the main power supply is on.
- Ensure that the neon lamps are illuminated.

6.2 When servicing, always ensure that genuine Maestrowave spares are used.

